



Notes:

- [1] Culvert pipe with beveled end treatment (see [Chapter 1600](#)).
- [2] When the travel lanes are bituminous, a similar type may be used on the approaches.
- [3] For mailbox location, see [Chapter 1600](#).
- [4] ±8% difference from shoulder slope.
- [5] Vertical curves not to exceed a 31/4-inch hump or a 2-inch depression in a 10-foot chord.

Road Approach Design Templates B1 and C1
Exhibit 1340-4