

1 (January 4, 2010)
2 Before tensioning, the Contractor shall remove all side forms from the girders. The
3 Contractor shall not release the falsework supporting the superstructure, and shall
4 not place construction loads and other live loads on the superstructure, until the
5 job-cured 2-inch grout cubes, fabricated in accordance with WSDOT TM 813, reach
6 a minimum compressive strength of 800 psi in accordance with WSDOT FOP for
7 AASHTO T 106.