- (March 6, 2000) Measurement for preboring for \*\*\* \$\$1\$\$ \*\*\* pile will be per linear foot of hole drilled. 1 2