- (January 4, 2010) Rock bolts will be measured by the linear foot of rock bolt (unbonded plus bonded length) installed, successfully proof tested, and accepted. 1 2 3 4 5
- Rock dowels will be measured by the linear foot of rock dowel installed and accepted.