

Contents

Chapter 1	Design Policy	1-1
1-1	Introduction.....	1-1
1-2	Responsibility.....	1-1
1-3	Hydraulic Reports	1-3
1-3.1	Hydraulic Report Types	1-4
1-3.2	Preparing a Stormwater and Drainage Hydraulic Report	1-6
1-3.3	Hydraulic Report Submittal and Archiving.....	1-7
1-3.4	Hydraulic Report Revisions and Supplements	1-8
1-3.5	Hydraulic Reports and Design-Build Projects	1-8
1-3.6	Developers and Utility Agreements	1-8
1-3.7	Upstream and Downstream Analysis.....	1-8
1-3.8	Existing Stormwater Drainage Conveyance System.....	1-11
1-4	Storm Frequency Policy and Design Tools and Software.....	1-11
1-5	Hydraulic Report Review Schedule	1-12
1-5.1	Milestones and Scheduling.....	1-13
Chapter 2	Hydrology	2-1
2-1	Introduction.....	2-1
2-2	Selecting a Method.....	2-2
2-3	Drainage Basin.....	2-5
2-4	Site Basins.....	2-5
2-5	Cold Climate Considerations	2-5
2-5.1	Calculating Snowmelt.....	2-5
2-5.2	Additional Considerations	2-6
2-6	Rational Method.....	2-7
2-6.1	General	2-7
2-6.2	Runoff Coefficients.....	2-8
2-6.3	Time of Concentration	2-9
2-6.4	Rainfall Intensity.....	2-11
2-7	Single-Event Hydrograph Method: Santa Barbara Urban Hydrograph	2-14
2-7.1	Design Storm Hyetograph.....	2-14
2-7.2	Runoff Parameters	2-15
2-8	Continuous-Simulation Hydrologic Model (Western Washington Only)	2-18

2-8.1	Modeling Requirements.....	2-19
2-9	Published Flow Records.....	2-23
2-10	USGS Regression Equations	2-24
2-11	Existing Hydrologic Studies	2-25
2-12	Examples.....	2-25
2-13	Appendices.....	2-26

Chapter 3	Culvert Design	3-1
3-1	Introduction.....	3-1
3-2	Culvert Design Documentation	3-1
3-2.1	Hydraulic Reports	3-1
3-2.2	Required Field Data.....	3-2
3-2.3	Engineering Analysis.....	3-3
3-3	Hydraulic Design of Culverts.....	3-4
3-3.1	Culvert Design Considerations.....	3-5
3-3.2	Allowable Headwater	3-7
3-3.3	Tailwater Conditions.....	3-10
3-3.4	Flow Type	3-11
3-3.5	Velocities in Culverts: General	3-11
3-3.6	Culvert Hydraulic Calculations Form	3-12
3-3.7	Computer Programs.....	3-12
3-3.8	Example.....	3-12
3-4	Culvert End Treatments.....	3-12
3-4.1	Projecting Ends.....	3-13
3-4.2	Mitered End Sections	3-13
3-4.3	Flared End Sections	3-14
3-4.4	Headwalls.....	3-14
3-4.5	Wing Walls and Aprons	3-15
3-4.6	Improved Inlets.....	3-16
3-4.7	Energy Dissipators	3-17
3-4.8	Culvert Debris.....	3-18
3-5	Miscellaneous Culvert Design Considerations.....	3-18
3-5.1	Multiple Culvert Openings	3-19
3-5.2	Camber	3-19
3-5.3	Horizontal and Vertical Angle Points	3-19
3-5.4	Upstream Ponding	3-20
3-5.5	Miscellaneous Design Considerations: Siphons.....	3-20

Chapter 4	Open-Channel Flow	4-1
4-1	Introduction.....	4-1
4-2	Uniform Flow Calculations.....	4-1
4-3	Field Slope Measurements.....	4-2
4-4	Roadside Ditch Design Criteria	4-6
4-5	Critical Depth.....	4-7
4-6	Manning's Roughness Coefficients (n).....	4-8
4-7	Countermeasures for Stream Instability.....	4-10
	4-7.1 Bank Protection.....	4-10
	4-7.2 Rock for Bank Protection	4-10
	4-7.3 Channel Stabilization	4-13
Chapter 5	Drainage of Highway Pavements.....	5-1
5-1	Introduction.....	5-1
5-2	Hydrology	5-2
5-3	Highway Drainage	5-2
	5-3.1 Bridge Deck and Downstream End Drainage.....	5-2
	5-3.2 Slotted Drains and Trench Systems	5-3
	5-3.3 Drop Inlets.....	5-3
5-4	Gutter Flow and Inlet Spacing.....	5-3
	5-4.1 Capacity of Inlets on a Continuous Grade	5-5
	5-4.2 Capacity of Inlets at Sag Locations.....	5-6
5-5	Drainage Structures.....	5-10
	5-5.1 Inlet Structure Types	5-10
	5-5.2 Grate Types	5-13
5-6	Scupper Barrier.....	5-18
5-7	Hydroplaning and Hydrodynamic Drag.....	5-19
Chapter 6	Storm Sewer.....	6-1
6-1	Introduction.....	6-1
6-2	Design Criteria.....	6-3
6-3	Data for Hydraulic Reports.....	6-6
6-4	Storm Sewer Design: Manual Calculations.....	6-6
6-5	Storm Sewer Design: Computer Analysis	6-6
6-6	Hydraulic Grade Line.....	6-6

6-7	Drywells	6-8
6-8	Pipe Materials for Storm Sewers	6-8
6-9	Subsurface Drainage	6-8

Chapter 7 Water Crossings..... 7-1

7-1	Introduction.....	7-1
7-2	Existing Conditions	7-3
7-2.1	Reference Reach	7-4
7-2.2	Bankfull Width.....	7-6
7-2.3	Watershed and Land Cover	7-7
7-2.4	Geology and Soils.....	7-7
7-2.5	Fluvial Geomorphology.....	7-8
7-2.6	Flood Risk Assessment.....	7-20
7-2.7	Hydrology	7-21
7-3	Hydraulic Analysis.....	7-22
7-3.1	Tidal Crossings.....	7-22
7-4	Design.....	7-22
7-4.1	Determining Crossing Design Methodology for Documentation	7-23
7-4.2	Constraints	7-24
7-4.3	Channel Alignment.....	7-25
7-4.4	Channel Cross Section	7-25
7-4.5	Hydraulic Opening	7-26
7-4.6	Vertical Clearance	7-32
7-4.7	Buried Structures	7-35
7-4.8	Sediment	7-36
7-4.9	Total Scour.....	7-39
7-4.10	Lateral Migration for Water-Crossing Structures.....	7-39
7-4.11	Channel Complexity.....	7-41
7-4.12	Scour Countermeasures.....	7-52
7-4.13	Landscaping/Planting	7-54
7-5	Other Design Methods	7-55
7-5.1	No-Slope Design	7-55
7-5.2	Fish Passage Improvement Structures.....	7-55
7-5.3	Tidal Crossing Structures.....	7-56
7-6	Structure-Free Zone.....	7-57
7-7	Temporary Stream Diversions.....	7-57

7-8	Monitoring.....	7-598
7-8.1	Streambed Camera Monitoring.....	7-59
7-9	Performance Management	7-59
7-10	Additional Resources.....	7-61
7-11	Appendices.....	7-61

Chapter 8 Pipe Classifications and Materials.....8-1

8-1	Introduction.....	8-1
8-2	Pipe Classifications	8-2
8-2.1	Drain Pipe	8-2
8-2.2	Underdrain Pipe.....	8-2
8-2.3	Culvert Pipe.....	8-2
8-2.4	Storm Sewer Pipe.....	8-8
8-2.5	Sanitary Sewer Pipe.....	8-8
8-3	Pipe Materials	8-8
8-3.1	Concrete Pipe	8-9
8-3.2	Metal Pipe: General	8-10
8-3.3	Thermoplastic Pipe: General.....	8-13
8-4	Pipe Corrosion Zones and Pipe Alternative Selection.....	8-16
8-4.1	Corrosion Zone I.....	8-17
8-4.2	Corrosion Zone II.....	8-17
8-4.3	Corrosion Zone III	8-18
8-5	Corrosion.....	8-25
8-5.1	pH.....	8-25
8-5.2	Resistivity.....	8-26
8-5.3	Corrosion Control Methods.....	8-26
8-6	Abrasion	8-27
8-7	Pipe Joints	8-28
8-8	Pipe Anchors.....	8-29
8-8.1	Thrust Blocks	8-29
8-9	Pipe Rehabilitation: Trenchless Technology.....	8-30
8-9.1	Trenchless Techniques for Pipe Rehabilitation.....	8-32
8-10	Pipe Design	8-33
8-10.1	Categories of Structural Materials: Rigid or Flexible	8-33
8-10.2	Structural Behavior of Flexible Pipes	8-33
8-10.3	Structural Behavior of Rigid Pipes.....	8-34

	8-10.4	Foundations, Bedding, and Backfill.....	8-35
8-11		Abandoned Pipe Guidelines.....	8-36
8-12		Structural Analysis and Fill Height Tables.....	8-38
	8-12.1	Pipe Cover	8-39
	8-12.2	Shallow Cover Installation.....	8-39
	8-12.3	Fill Height Tables.....	8-40
Chapter 9		Highway Rest Areas	9-1
Chapter 10		Woody Material	10-1
10-1		Introduction.....	10-1
	10-1.1	Purpose and Need.....	10-1
	10-1.2	Guidance for Emergency Large Woody Material Placement.....	10-2
	10-1.3	Design Oversight.....	10-2
10-2		Design Process	10-2
10-3		Reach Assessments	10-3
10-4		Recreational Waters Safety Assessment	10-5
10-5		Project Objectives.....	10-6
10-6		General Design Criteria.....	10-7
	10-6.1	Design Life.....	10-7
	10-6.2	Wood Selection	10-8
	10-6.3	Design Flow.....	10-11
	10-6.4	Placement	10-12
	10-6.5	Stability and Anchoring.....	10-13
	10-6.6	Scour.....	10-16
	10-6.7	FEMA Floodplain and Floodways	10-17
	10-6.8	Recreational Safety in Navigable Waters.....	10-17
10-7		Project-Specific Design Criteria	10-18
	10-7.1	Bridge Scour and Bank Stabilization.....	10-18
	10-7.2	Stream Habitat Restoration	10-18
	10-7.3	Wood for Aquatic Habitat Design Process.....	10-20
10-8		Mobile Woody Material.....	10-28
	10-8.1	Design Criteria	10-30
	10-8.2	Design Flows for Mobile Woody Material.....	10-30
10-9		Small Woody Material and Slash	10-30
	10-9.1	Benefits of Using Small Woody Material and Slash.....	10-31

10-9.2	Design of Small Woody Material/Slash.....	10-32
10-10	Inspection and Maintenance.....	10-32
10-11	Appendices	10-32
Glossary and Sources.....		G-1
	Abbreviations	G-1
	Main Glossary of Terms	G-6
	Sources	G-18

Figures

Chapter 1

Design Policy

Figure 2-1	Extended Precipitation Time Series Regions.....	2-21
Figure 2-2 Regions	Precipitation Station Selection outside Extended Precipitation Time Series	2-22
Figure 2-3	Rational Formula Example.....	2-26
Figure 3-1	Headwater and Tailwater Diagram	3-8
Figure 3-2	Roadway Overtopping	3-9
Figure 3-3	Typical Bottomless Culvert.....	3-10
Figure 3-4	Projecting End.....	3-13
Figure 3-5	Beveled End Section.....	3-14
Figure 3-6	Headwall	3-15
Figure 3-7	Modified Wing Wall for Circular Pipe.....	3-16
Figure 3-8	Rock-Protected Outlet.....	3-17
Figure 3-9	Camber under High Fills	3-19
Figure 3-10	Culvert Angle Point	3-20
Figure 3-11	Typical Twin-Barrel Inverted Siphon	3-21
Figure 4-1	Field Slope Measurement of Uniform Flow Channels Plan View	4-3
Figure 4-2	Field Slope Measurement of Uniform Flow Channels Section View.....	4-3
Figure 4-3	Field Slope Measurement of Non-Uniform Flow Channels Plan View.....	4-4
Figure 4-4	Field Slope Measurement of Non-Uniform Flow Channels Section View	4-4
Figure 4-5	Field Slope Measurement of Uniform Flow Channels Profile View	4-5
Figure 4-6	Field Slope Measurement of Non-Uniform Flow Channels Profile View.....	4-5
Figure 4-7	Drainage Ditch Detail.....	4-7
Figure 4-8	Typical Cross Section of Rock Bank Protection Installation	4-12
Figure 5-1	Sag Analysis.....	5-7

Figure 5-2	Grate Inlet Type 1 Structure.....	5-11
Figure 5-3	Grate Inlet Type 2 Structure.....	5-12
Figure 5-4	Rectangular Vaned Grate and Rectangular Bi-Directional Vaned Grate	5-14
Figure 5-5	Section and Isometric View Combination Inlet Frame, Hood, and Vaned Grate.....	5-15
Figure 5-6	Grates A and B.....	5-16
Figure 5-7	Frame and Vaned Grates for Installation on Grate Inlet.....	5-16
Figure 5-8	Circular Grate.....	5-17
Figure 5-9	Herringbone Pattern	5-17
Figure 6-1	Storm Sewer Configurations.....	6-2
Figure 7-1	Reference Reach Determination.....	7-6
Figure 7-2	WSDOT Lateral Migration Risk Assessment Process.....	7-11
Figure 7-3	Styles of Knickpoint Evolution	7-18
Figure 7-4	Potential Deliverables for Permitting Process	7-21
Figure 7-5	Final Design Cross Section.....	7-26
Figure 7-6	Minimum Hydraulic Width and MHO	7-27
Figure 7-7	Formation of an Armor Layer	7-38
Figure 7-8	Total Scour Components without Potential of Lateral Migration.....	7-40
Figure 7-9	Total Scour Components with Potential of Lateral Migration.....	7-41
Figure 7-10	Meander Bar Detail	7-43
Figure 7-11	Typical Stream Morphologies Suitable for Meander Bar Application.....	7-44
Figure 7-12	Range of Slopes Suitable for Meander Bar Application	7-45
Figure 7-13	Meander Bar Spacing Detail	7-47
Figure 7-14	Forced Bar vs. Free Bar Threshold	7-47
Figure 7-15	Typical Point Bar Formation in Meandering Streams.....	7-50
Figure 7-16	Example Velocity Maps.....	7-51

Figure 7-17	Example of a Constructed Meander Bar with Slash	7-52
Figure 7-18	Scour Countermeasure Design with Deep Foundation and Calculated Abutment Scour Greater than Zero	7-54
Figure 7-19	Scour Countermeasure Design with Deep Foundation and Calculated Abutment Scour of Zero	7-54
Figure 7-20	WSDOT's Performance Management Process.....	7-60
Figure 8-1	Typical Soil Pressure Surrounding a Pipe Arch	8-4
Figure 8-2	Concrete Thrust Beams Used as Longitudinal Stiffeners	8-5
Figure 8-3	Typical Corrugation Section.....	8-11
Figure 8-4	Typical Spiral Rib Section	8-12
Figure 8-5	Typical Profile Wall PVC Cross Sections.....	8-16
Figure 8-6	Washington State Corrosion Zones	8-19
Figure 8-7 Treatments	Corrosion Zone I: Flow Chart of Acceptable Pipe Alternatives and Protective Treatments	8-20
Figure 8-8	Corrosion Zone I: Acceptable Pipe Alternatives and Protective Treatments...	8-21
Figure 8-9	Corrosion Zone II: Flow Chart of Acceptable Pipe Alternatives and Protective Treatments	8-22
Figure 8-10	Corrosion Zone II: Acceptable Pipe Alternatives and Protective Treatments..	8-23
Figure 8-11	Corrosion Zone III: Flow Chart of Acceptable Pipe Alternatives and Protective Treatments	8-24
Figure 8-12	Corrosion Zone III: Acceptable Pipe Alternatives and Protective Treatments.	8-25
Figure 8-13	Replace or Rehabilitate Decision Tree.....	8-31
Figure 8-14	Deflection of Flexible Pipes	8-34
Figure 8-15	Zones of Tension and Compression in Rigid Pipes	8-35
Figure 8-16	Decision Tree for Pipe(s) to be Abandoned.....	8-37
Figure 8-17	Pipe abandonment determination schematic.....	8-38
Figure 10-1	Wood Design Process.....	10-3
Figure 10-2	Property Damage Risk Matrix	10-5

Figure 10-3	Design Flow Risks Occurring during Project Life	10-12
Figure 10-4	Example of Small-Channel Complex Log Grade Control	10-26
Figure 10-5	Example of Grade-Control Wood Used in Conjunction with Rock	10-27
Figure 10-6	Example of Large-Channel Wood Grade Control.....	10-28
Figure 10-7	Ratio of MWM Initiator Log Length to Culvert Diameter	10-29

Tables

Chapter 1

Design Policy

Table 1-1	Hydraulic Report Documentation.....	1-5
Table 1-2	Design Reference.....	1-12
Table 1-3	Hydraulic Report Review Schedule.....	1-13
Table 2-1	Methods for Estimating Runoff Rates and Volumes.....	2-4
Table 2-2	Runoff Coefficients for the Rational Method: 10-Year Return Frequency.....	2-9
Table 2-3	Ground Cover Coefficients.....	2-11
Table 2-4	Inches to Rainfall Coefficients.....	2-13
Table 2-5	Total Five-Day Antecedent Rainfall.....	2-17
Table 2-6	Relationship between NRCS Hydrologic Soil Group and MGSFlood Soil Group.....	2-23
Table 3-1	Field Data Requirements for Hydraulic Reports and Specialty Reports.....	3-3
Table 3-2	Information for the Hydraulics and Specialty Reports for New Culverts and for Extending/Replacing Existing Culverts.....	3-4
Table 3-3	Outlet Protection Material Size.....	3-18
Table 4-1	References for Manning’s Roughness Coefficients.....	4-9
Table 4-2	Manning’s Roughness Coefficients (n) for Quarry Spalls and Rock for Erosion and Scour Protection.....	4-10
Table 5-1	Design Frequency and Allowable Spread.....	5-5
Table 5-2	Properties of Grate Inlets.....	5-18
Table 6-1	Minimum Storm Sewer Slopes.....	6-4
Table 7-1	Flood Event for Hydraulic Design Elements.....	7-23
Table 7-2	100-Year Design Freeboard Requirements on Buried Structures.....	7-32
Table 7-3	Maintenance Clearance for Complexity Features ^a	7-35
Table 8-1	Pipe Abrasion Levels.....	8-28
Table 8-2	Concrete Pipe.....	8-40

Table 8-3	Concrete Pipe for Shallow Cover Installations	8-40
Table 8-4	Corrugated Steel Pipe: 2 $\frac{2}{3}$ in. \times $\frac{1}{2}$ in. Corrugations—AASHTO M 36	8-41
Table 8-5	Corrugated Steel Pipe: 3 in. \times 1 in. Corrugations—AASHTO M 36	8-41
Table 8-6	Corrugated Steel Pipe: 5 in. \times 1 in. Corrugations—AASHTO M 36	8-42
Table 8-7	Corrugated Steel Structural Plate Circular Pipe: 6 in. \times 2 in. Corrugations.....	8-43
Table 8-8	Corrugated Steel Pipe Arch: 2 $\frac{2}{3}$ in. \times $\frac{1}{2}$ in. Corrugations—AASHTO M 36.....	8-44
Table 8-9	Corrugated Steel Pipe Arch: 3 in. \times 1 in. Corrugations—AASHTO M 36	8-45
Table 8-10	Corrugated Steel Structural Plate Pipe Arch: 6 in. \times 2 in. Corrugations	8-46
Table 8-11	Aluminum Pipe: 2 $\frac{2}{3}$ in. \times $\frac{1}{2}$ in. Corrugations—AASHTO M 196	8-47
Table 8-12	Aluminum Pipe: 3 in. \times 1 in. Corrugations—AASHTO M 196	8-47
Table 8-13	Aluminum Structural Plate: 9 in. \times 2 in. Corrugations with Galvanized Steel Bolts	8-48
Table 8-14	Aluminum Pipe Arch: 2 $\frac{2}{3}$ in. \times $\frac{1}{2}$ in. Corrugations—AASHTO M 196.....	8-48
Table 8-15	Aluminum Pipe Arch: 3 in. \times 1 in. Corrugations—AASHTO M 196	8-49
Table 8-16	Aluminum Structural Plate Pipe Arch: 9 in. \times 2 $\frac{2}{3}$ in. Corrugations, $\frac{1}{4}$ in. Steel Bolts, 4 Bolts/Corrugation	8-49
Table 8-17	Steel and Aluminized Steel Spiral Rib Pipe: $\frac{3}{4} \times 1 \times 11\frac{1}{2}$ in. or $\frac{3}{4} \times \frac{3}{4} \times 7\frac{1}{2}$ in. Corrugations—AASHTO M 36.....	8-50
Table 8-18	Aluminum Alloy Spiral Rib Pipe: $\frac{3}{4} \times 1 \times 11\frac{1}{2}$ in. or $\frac{3}{4} \times \frac{3}{4} \times 7\frac{1}{2}$ in. Corrugations— AASHTO M 196	8-51
Table 8-19	Thermoplastic and Ductile-Iron Pipe	8-51
Table 10-1	Physical Characteristics of Woods Found in the Pacific Northwest	10-10
Table 10-2	Large Wood Target Metrics.....	10-22