Contents

Chapter 1 General Information 1-1
1.1 Introduction 1-1
1.2 Considerations 1-2
1.3 Work Duration 1-4
1.4 Personal Attributes 1-4
1.4.1 Worker Protection 1-4
1.5 Personal Protective Wear 1-5
1.6 Equipment 1-5
1.6.1 Traffic Control Device Crashworthy Requirements 1-5
1.6.2 Condition and Care of Equipment 1-5
1.6.3 Signs 1-5
1.6.4 Vehicles 1-6
1.6.5 Portable Changeable Message Signs (PCMS) 1-7
1.6.6 Arrow Boards 1-8
1.6.7 Channelizing Devices 1-8
1.6.8 Barricades 1-9
1.6.9 Positive Protection Devices 1-9
1.6.10 Temporary Concrete Barrier 1-9
1.6.11 Truck Mounted Attenuators 1-10
1.6.12 Warning Lights 1-11
1.6.13 Flares 1-11
1.6.14 Portable Signal Systems 1-11
1.6.15 Automated Flagger Assistance Device (AFAD) 1-12
1.6.16 Portable Highway Advisory Radio (HAR) 1-12
1.7 Flagging 1-12
1.8 Pedestrians, Bicycles, and Other Roadway Users 1-14
1.8.1 Pedestrians 1-14
1.8.2 Bicycles 1-14
1.8.3 Motorcycles 1-15
1.8.4 Schools 1-15
1.9 Additional Work Zone Considerations 1-15
1.9.1 Work Zone Speed Limits 1-15
1.9.2 Buffer Space and Shy Distance 1-15
1.9.3 Lane Closure Setup/Takedown 1-16
1.9.4 Survey Work Zones 1-16
1.9.5 Public Information 1-16
1.9.6 Roundabout Traffic Control 1-17
1.9.7 Road Closures 1-17
1.9.8 Detour 1-18
1.9.9 Special Events 1-18
1.9.10 Work Over Traffic 1-18

Chapter 2 Stationary Work Zones 2-1
TCP 1 Typical Alternating One-Way Traffic Flagger Controlled 2-3
TCP 2 Typical Pilot Car Operation 2-4
TCP 3 Typical Single-Lane Closure for Multi-Lane Roadways 2-5
TCP 4 Typical Double-Lane Closure for Multi-Lane Roadways. 2-6
TCP 5 Typical Shoulder Closure – Low Speed (40 mph or Less) 2-7
TCP 6 Typical Shoulder Closure – High Speed (45 mph or Higher). 2-8
TCP 7 Typical Temporary Off-Ramp for Multi-Lane Roadways 2-9
TCP 8 Typical Temporary On-Ramp for Multi-Lane Roadways. 2-10
TCP 9 Typical Short-Term Temporary On-Ramp for Multi-Lane Roadways . . . 2-11
TCP 10 Typical Right Lane Closure With Shift – 5 Lane Roadway 2-12
TCP 11 Typical Left Lane and Center Turn Lane Closure – 5 Lane Roadway . . . 2-13
TCP 12 Typical Lane Shift – Three Lane Roadway 2-14
TCP 13 Typical Short-Term Ramp Closure (On-Ramp and Off-Ramp) 2-15
Chapter 3 Short Duration Work Zones 3-1
3.1 Introduction 3-1
3.2 Guidance 3-1
3.3 Key Elements of Short Duration Work Zones 3-3
3.4 Short Duration Work Zone Condition 3-3
3.5 Consideration and Assessment of Traffic Volumes in Work Zones 3-4
3.5.1 Work Zone Type. 3-4
3.5.2 Traffic Conditions 3-5
3.6 Very Short Duration Work Zones. 3-6
3.7 Short Duration Work Zone Rules. 3-7
3.8 Short Duration Don’ts and Dos 3-8
3.9 Short Duration and Very Short Duration TCPs 3-9
TCP 14 Typical Short Duration Lane Closure (Two-Lane, Two-Way Highway Application). 3-11
TCP 15 Typical Short Duration Lane Closure (Multi-Lane Freeway and Highway Application). 3-12
TCP 16 Typical Short Duration Shoulder Work (Multi-Lane Application). 3-13
TCP 17 Typical Short Duration Work Operation (Intersection Application). 3-14
TCP 18 Typical Very Short Duration Work Operation (Outside Traveled Way) (Two-Lane or Multi-Lane Highways). 3-15
TCP 19 Typical Very Short Duration Work Operation (Multi-Lane Application, Low Speed, 40 mph or Lower) 3-16
TCP 19a Typical Very Short Duration In-lane Work (Multi-Lane Freeway and Highway Application, High Speed, 45 mph or Higher). 3-17
TCP 20 Typical Very Short Duration Lane Closure (Two-Lane Highway). 3-18
TCP 21 Typical Very Short Duration Work Operation (Intersection Application) 3-19

Chapter 4 Mobile Operations 4-1
TCP 22 Typical Mobile Left Shoulder Closed (Freeway Application) 4-2
TCP 23 Typical Mobile Left-Lane Operation (Freeway Application) 4-3
TCP 24 Typical Mobile Middle-Lane Operation (Freeway Application) 4-4
TCP 25 Typical Mobile Lane Closure Operation on a Two-Lane Roadway 4-5
TCP 26 Typical Mobile Shoulder Closure Operation on a Two-Lane Roadway 4-6

Chapter 5 Intersection Operations 5-1
TCP 27 Typical Intersection Lane Closure – Three-Lane Roadway 5-2
TCP 28 Typical Intersection Lane Closure – Five-Lane Roadway 5-3

Chapter 6 Special Details and TCPs 6-1
TCD 1 Shoulder Work Area Protection During Non-Working Hours 6-3
TCD 2 Typical Example – Motorcycle Warning Sign Detail 6-4
TCD 3 Typical Example – Lane Closure With Shift 6-5
TCD 4 Typical Example – Speed Zone Detail for Chip Seal Project 6-6
TCD 5 Typical Example – Work Beyond the Shoulder 6-7
TCD 6 Typical Long-Term Shoulder Closure on High Speed Roadway 6-8
TCD 7 Rolling Slowdown 6-9
TCD 7 Typical Example – Rolling Slowdown 6-11
TCD 8 Emergency Operations 6-12
TCD 8 Typical Example – Emergency Operations 6-13
TCD 9 Temporary Pavement Marking Details 6-14
TCD 10 Typical Example – Temporary Intersection Pedestrian Traffic Control . . 6-15
TCD 11 Typical Example – Temporary Portable Signal 6-16
TCD 12 Typical Example – Automated Flagger Assistance Device (AFAD) 6-17
TCD 13 Typical Example – Work Within a Roundabout 6-18
TCD 14 Typical Mobile Shoulder Operation With Encroachment on a Two-Lane Roadway 6-19
TCD 15 Typical Temporary Exit Gore Channelization Plan 6-20

Appendix 1 Taper/Channelizing Device Table A-1

Appendix 2 Reference Manuals A-3

Appendix 3 Taper and Buffer Space Details A-5