


NOTES

1. ALL CONCRETE POST BASES SHALL BE 10" (IN) MINIMUM DIAMETER. 2. ALONG THE TOP AND BOTTOM USING HOG BRACE POST RINGS, FASTEN THE CHAIN LINK FENCE FABRIC TO THE TENSION WIRE WITHIN THE LIMITS OF THE FIRST FULL FABRIC WEAVE. 3. DETAILS ARE ILLUSTRATIVE AND SHALL NOT LIMIT HARDWARE DESIGN OR POST SELECTION OF ANY PARTICULAR TYPE. TIE WIRES (TYP.) ~ SPACED @ 14" (IN) MAX. TENSION BAR FABRIC POST TENSION BAND ~ SPACED 15" (IN) MAX. BRACE POST METHOD OF FASTENING STRETCHER BAR TO POST TIE WIRES (TYP.) ~ SPACED @ 14" (IN) MAX.

itate		plan ref no FS-1.1 sheet 1
sportation	CHAIN LINK FENCE WITH EYE BOLTS	OF 2 SHEETS



T TENSION WIRE

TENSION WIRES

State sportation	CHAIN LINK FENCE WITH EYE BOLTS	SHEET 2 OF 2 SHEETS
		PLAN REF NO FS-1.1
		Plot 2