

1
2
3
4
5
6
7
8

(June 26, 2000)

Drilling Holes for, and Setting, Dowels for Conc. Box Culvert Extension

After removing the specified portions of the box culvert, the Contractor shall drill 1-3/8 inch diameter holes into the exposed concrete face for the placement of #9 dowel bars between the existing concrete and the box culvert extension. The holes shall be 12 inches deep, minimum, and shall be spaced at 12 inch centers. The #9 dowels shall be of sufficient length to provide a 2'-0" minimum extension into the box culvert extension.